


## Applying SELECT Soft Cotton or

## **SELECT Soft Machine Batting**

## TUTORIAL

These battings feature a temporary, two-sided water-soluble fusible coating, which eliminates pinning and controls stretching and movement during embellishing. Follow the steps below to help with your next quilting venture.



1. Read and follow all directions for use and care on package. Prepare batting on a flat ironing surface and lightly spray, do not over-saturate, with a misting/spray bottle filled with water. Apply wrong side of backing fabric to the misted area of the batting.



**2.** Press evenly, one section at a time and let cool to room temperature before advancing. If there's a wrinkle in the fabric it should separate from the batting with moderate resistance. Simply repeat the mist and iron process.





**3.** After the fabric is adhered, flip over the batting and repeat the process if desired with the top of the quilt. No Pinning!

**4.** Once the piece is quilted or embellished it can be laundered in warm water. The fusible fibers will wash away in warm water (at or above 110 F°) and mild soap. DO NOT USE COLD WATER! If any adhesion remains after washing, increase the water temperature and rewash.

Remember! This fusible feature is for basting only! It is not necessary to hold excessive pressure with your iron.





## QUILTERS SELECT.COM